

# Osmium MIMU4444

## Logging Sensors' Data Using USB

---

### Instruction Manual

### Revision 1.0

**Registered Office:****GT Silicon Pvt Ltd**

LIG – 1398, Avas Vikas – 3

P.O. – NSI, Kalyanpur,

Kanpur (UP), India, PIN – 208017

**R&D Centre:****GT Silicon Pvt Ltd**

S6, SIDBI Innovation & Incubation  
Centre, IIT Kanpur

Kanpur (UP), India, PIN – 208016

Tel: +91 512 259 6664

Fax: +91 512 259 6177

Email: [info@gt-silicon.com](mailto:info@gt-silicon.com)

URL: [www.gt-silicon.com](http://www.gt-silicon.com)

© 2014, GT Silicon Pvt Ltd, Kanpur, India

## Revision History

Revision	Revision Date	Updates
1.0	13 Oct 2014	Initial Release of Instruction Manual

## Purpose & Scope

This document lists down instructions to collect and plot data from all the accelerometers' and gyroscopes' present in Osmium MIMU4444 module, using USB.

## Hardware & Software Requirement

- Operating System: 64-bits Windows 7
- Matlab R2013
- Matlab scripts for data collection (Should be available on your computer.)
- Hardware: A computer with 4 GB SRAM
- USB data cable
- Osmium MIMU4444 (Pre programmed with OpenShoe code)

## Live Demo Video with Operating Instructions


A live video is available online:

<https://www.youtube.com/watch?v=ey0U16Jmjic>

Same instructions are listed in the following section.


## Operating Instructions

1. Connect MIMU4444 with computer using USB data cable. MIMU4444 draws its power from USB.
2. Open “Device Manager”




Note the connected COM Port (COM7).

4. Open Matlab and select **logging\_inertial\_data3.m** for viewing




5. Update COM Port in the **logging\_inertial\_data3.m** file and save. Make sure that line no. 36 and 37 are uncommented and line no. 32 to 35 are commented in the same file.




```

16 %> documented well by the doxygen. See script files for further
17 %> documentation.
18 %> @{}
19
20 % Clear workspace
21 - clear all, clc
22 - format compact
23
24 % Open serial port
25 - com = serial('COM7', 'BaudRate', 460800, 'InputBufferSize', 10000);
26 - fopen(com);
27
28 % Open binary file for saving inertial data
29 - file = fopen('imu_data.bin', 'w');
30
31 % Tell OpenShoe to output inertial data at every interrupt
32 % nr_imus=4;
33 % fwrite(com, [40 0 0 0 15 1 0 56], 'uint8');
34 %nr_imus=18;
35 %fwrite(com, [40 0 3 255 255 1 2 42], 'uint8');
36 - nr_imus=32;
37 - fwrite(com, [40 255 255 255 255 1 4 37], 'uint8');
38 - fread(com, 4, 'uint8')
39
40 % Open dummy figure with pushbutton such that logging can be aborted
41 - abort = 0;
42 - figure(3);
43 - uicontrol('style','push','string','Abort data logging','callback','abort=1;');
44 - drawnow
45
46 % Logg data until pushbutton pressed
47 - while abort==0
  
```

6. Run **logging\_inertial\_data3** from Matlab command prompt




7. Shake MIMU4444 gently as shown in the video.
8. Click on Abort button of the Matlab figure which popped up on screen, on executing logging\_inertial\_data






9. On clicking Abort button, two plots (one on top of other) would pop up on screen



Accelerometers' data from all four IMUs

Gyroscopes' data from all four IMUs



Zoom into the graph to note data corresponding to all the sensors present on board

Note:

- Please restart Matlab, if it gives communication error.